Digital Radio Example: FM modulation and demodulation in an FPGA

IEEE-Denver Signal Processing Society February 19, 2009

David Farrell Dane Sprister Matthew Taylor

Colorado Electronic Product Design, Inc.

rev 1

Topics

- Introduction
- Abstract
- System Block Diagram
- Up/Down Conversion
- Modulation
- Demodulation
- Demonstration System
- Questions

Introduction


Colorado Electronic Product Design is an engineering consulting company in Boulder, founded in 1996. Services we provide include:

- DSP
- Embedded Systems Hardware and Software
- Data Acquisition
- Telemetry Systems
- Motor Control Systems
- Programmable Logic: FPGA / CPLD / EPLD
- Analog Circuit Design
- Switching Power Supply Design
- PCB Design and Layout
- Analysis and Documentation

Abstract

This presentation by Colorado Electronic Product Design explores an FPGA based configurable digital radio, and demonstrates an FM transceiver design. The trend in software radios is moving toward an all-digital design within a single chip. Most elements of a digital radio can now be implemented within an FPGA. A high-speed analog to digital converter board and an FPGA board are used to implement a working radio using VHDL.

Hardware Transceiver Implementation



The platform is fairly flexible

- The impedance of the PCB signal paths are wideband and 50 ohm
- Mixers, which can be bypassed, are provided for up/down conversion
- Key components are socket-ed, different bands can be targeted by changing out filters, etc.
- The ADC and DAC support over 200 MSPS
- The main signal processing algorithms are performed by a configurable FPGA

Up/Down Conversion Some Trigonometry

A real mixer produces sum and difference tones or spectra:

sin($\omega_c t$) • sin($\omega_{Lo} t$) = ½ cos(($\omega_c - \omega_{Lo})t$) - ½ cos(($\omega_c + \omega_{Lo})t$) Filtering is required to select only the desired component.

A complex or quadrature mixer produces a single tone or spectra:

$$e^{j} \omega_{c} t \cdot e^{-j} \omega_{Lo} t = e^{j} (\omega_{c} \cdot \omega_{Lo}) t$$

<mark>0ľ</mark>

[$\cos(\omega_c t) + j \sin(\omega_c t)$] · [$\cos(\omega_c t) - j \sin(\omega_c t)$] = $\cos((\omega_c - \omega_{LO})t) + j \sin((\omega_c - \omega_{LO})t)$ The mixer complexity is doubled, real and imaginary or in phase and quadrature paths are required.

Quadrature Detection Trigonometry

Φ is the desired time varying signal sin(ω_c t + Φ) • cos(ω_c t) = ½ sin(Φ) + ½ cos(ω_c t + Φ) Filter out the carrier and the signal remains ½ Φ ≈ ½ sin(Φ), for Φ < π/4

Real Down Conversion – Moving the carrier to the IF


- Mixing the carrier with a real local oscillator



The mixed signal contains two frequencies:

• $\omega_{\rm C}$ - $\omega_{\rm LO}$ and $\omega_{\rm C}$ + $\omega_{\rm LO}$

- If the local oscillator frequency is chosen to be $\omega_{\rm C} - \omega_{\rm IF}$, the two resultant frequencies are: $\omega_{\rm IF}$ and 2 $\omega_{\rm C}$ - $\omega_{\rm IF}$



Real Up Conversion – Moving the IF to the Carrier frequency

Mixing the IF with a real local oscillator



The mixed signal contains two frequencies:


• ω_{LO} - ω_{IF} and ω_{LO} + ω_{IF}

- If the local oscillator frequency is chosen to be $\omega_{\rm C}$ - $\omega_{\rm IF}$, the two resultant frequencies are: $\omega_{\rm C}$ and $\omega_{\rm C}$ - $2\omega_{\rm IF}$


$$DC \qquad \omega_{IF} \qquad (\omega_{LO}^{-}\omega_{IF}) \qquad \omega_{LO} \qquad \omega_{C} \qquad (\omega_{LO}^{+}\omega_{IF})$$

Bandpass Sampling

- Undersampling is a method that uses a sampling frequency below the Nyquist rate for the signal of interest
- It intentionally aliases an image of the signal into the digitized spectrum
- Works if the Bandwidth of the desired signal is less than ¹/₂ the sample frequency



FM Modulation



Purpose

The purpose of this section is to:


- Present algorithms for implementation of an FPGA controlled FM modulator.
- Present a hardware platform that can be used to implement the design of different modulation implementations.

Outline of this section

- Overview of FM Radio and FM Radio sub carriers
- Outline of Direct Digital Synthesis Architecture
- Implementation of Modulator Reference design
- Overview of the Analog Board

Overview of FM Modulation

- Commercial FM radio broadcasts at 88MHz to 108MHz
- There is a separation of 200kHz between adjacent stations.
- The peak frequency deviation is 75kHz.
- The left and right channels are added and subtracted to generate L+R and L-R.
- The L+R (monophonic) and L-R (stereo) signals are preemphasized.
- The L-R signal is modulated and added to the L+R and 19kHz pilot signal prior to the FM modulator block.



Implementing FM Modulator in VHDL

- Signal to be transmitted is a monophonic signal.
 - Left and right channels are not present, so they do not need to be added and subtracted to get L+R and L-R.
 - Because left and right channels are not both present a 19kHz pilot is not required.
- Preemphasis is not used.
- The input audio signal is not DSB-SC for a 38KHz carrier (because there is no pilot signal).

DDS Architecture

• The FM reference design uses DDS architecture to modulate the line in signal.




Figure courtesy of Analog Device's "A Technical Tutorial on Digital Signal Synthesis"

Overview of DDS Architecture

• The phase accumulator:

- Tracks the phase of the sine wave.
- Uses a modulus n counter to allow the sine wave frequency to change quickly using a tuning word.
- Is incremented every system clock cycle by the value of the tuning word.





Figure courtesy of Analog Device's "A Technical Tutorial on Digital Signal Synthesis"


Overview of DDS Architecture

- The output of the phase accumulator is connected to a phase to amplitude converter.
 - The value of the phase accumulator is truncated and mapped to a sine wave lookup table.
 - Without phase accumulator truncation, the amount of memory required for the lookup table is too large.



VHDL Implementation

- Several components were used to implement the modulator:
 - PCM3500 audio CODEC component to read ADC values from the line in port.
 - FM Modulator Modulator component contains the phase accumulator and converters to calculate amplitude to frequency and frequency to tuning word.
 - Sine Wave Look up Table.
 - Dac5674 output sine wave to Digital to Analog Converter




PCM3500

- This component interfaces with the PCM3500 16-bit audio CODEC.
- This component shifts the 16-bit ADC value from the audio CODEC serially and stores the value in a 16-bit register.

FM Modulator


- The audio CODEC value is converted from 2's compliment to a binary offset value.
- The value is then converted from an amplitude to a frequency.
- The frequency is converted to a tuning word value.
- The values used for conversions are Q16, so the values are converted back to Q0 values by shifting the values.
- The tuning word is added to a pre-calculated tuning word for 10.625MHz.
- The tuning word is added to the value in the phase accumulator (this tuning word is added to the phase accumulator every system clock cycle).
- The phase accumulator value is output to the top.vhd level.

FM Modulator Block Diagram



Sine Wave Look-up Table


- The phase accumulator value is truncated and the top 14 bits are taken into the sine wave lookup table component as an address.
- 16,384 amplitude points making up a full cycle of a sine wave are stored in this component as an integer array (8-bit values).
- The 8-bit amplitude value is output to the top.vhd level for output to the Digital to Analog Converter.




dac5674

- The 8-bit amplitude value from the sine wave lookup table is placed in an output register in the top.vhd level (placed in the top 8-bits of the 14-bit DAC output register).
- The output register is mapped to the dac5674 component.
- The 14-bit output register is clocked out to the DAC and, if the Transmit/Receive switch is depressed, transmitted.

Block Diagram




Analog Up-Converter





Digital FM Demodulator Through Quadrature Detection


Analog Down Converter



Down Converter Stages

- Band Select 3rd order passive Filter For FM Band (75MHz to 150MHz)
- +30dB Low Noise Amplifier
- Mixer for 10.7MHz IF, Local Oscillator is set by the FPGA
- +20dB Amplifier
- IF (10.7MHz) Filter
- ADC (ADS5440 ADC)

FPGA Demodulation Block Diagram



•Sample ADC at 66.5MHz


- Limiter
- Down Sample to 8.3125MHz
- Demodulate
- Down Sample to 24KHz
- Parallel to Serial data conversion
- 24KHz write to CODEC

Sampling Implementation

- The ADC samples a 10.7MHz IF at 66.5Mhz with 13bits resolution
 - Significantly faster than IF of 10.7MHz provided by the analog down converter.
- ADC provides a Data Ready signal for latching the data bus.
- ADC data is in binary offset. Binary offset is converted to 2's complement.
 - This is done by inverting the most significant bit of the ADC data register.

Limiter Implementation

- A limiter is used to improve signal to noise ratio.
- The limiter hysteresis band is set to +-120 ADC counts. This squelches the ADC input noise.
- Similar to a comparator design in the analog domain.
- Output level is set to 50% of full scale to prevent overflow.
- When sampling a FM signal there is no information in the amplitude.
- Perform sign extension from 13bits to 16bits.




Down Sample


- The 66.5MHz sample frequency is then down sampled to create a 8.3125MHz IF.
 - Latch every 8th sample
- The IF frequency of 10.7 MHz is sampled at 8.3125 MHz, producing a flipped image at 5.925 MHz and a positive image at 2.3875 MHz.
- A center frequency of 2.3875Mhz will be chosen for the band pass filter, removing the 5.925Mhz reflection.



FM Demodulator Stages




FM Quadrature Demodulator




#	Description	Signal Processing
1	Input Signal	sin(2π f _{IF} t)
2	Hilbert Transform Q = $\pi/2$ phase shift	$I = sin(2\pi f_{IF} t)$ Q =cos(2\pi f_{IF} t)
3	Band Pass Filter	$Q2 = \cos(2\pi f_{IF} t + \Phi)$
4	Multiplier I*Q2	$sin(2\pi f_{IF}t) cos(2\pi f_{IF}t + \Phi)$
5	Product to Sum Trig. Identity	½ sin (-Φ (f)) + ½ sin(4π f _{IF} t + Φ)
6	Low Pass Filter	½ sin (-Φ)
7	Recovered Base Band Output	½ sin (-Φ) ≈ ½ -Φ
© 2009 by CEPD, Inc. <u>www.cepd.com</u>		

2nd Order FIR used for the π / 2 phase shift (Hilbert Transform)





Hilbert Transform Response




© 2009 by CEPD, Inc. <u>www.cepd.com</u>

2nd Order IIR Biquad used for the Bandpass Filter







Bandpass Filter Response



Discrete time form of the Demodulator



Lowpass Filter Response



Suggested Reading

[1] Coffing, Danielle. Main, Eric. "Quadrature Demodulator," TechOnline, Paper 14378, Jun. 4, 2001

[2] Bilotti, Alberto. "Applications of a Monolithic

Analog Multiplier," IEEE Journal of Solid–State Circuits, Vol. SC–3, No. 4, December 1968.

[3] Hentschel. Fettweis. "Sample Rate Conversion for Software Radio," IEEE Communications Vol. 38, No. 8, pp. 142-150, August 2000.

[4] Stark, Henry. Tuteur, Franz B. "Modern Electrical Communications: Theory and Systems" Prentice-Hall Inc. 1979.

[5] Beach, Mark. MacLeod, John. Warr, Paul. Ed. Tuttlebee, Walter. "Software Defined Radio: <u>Enabling Technologies.</u>" John Wiley & Sons, Ltd. 2002.

[6] Rohde, Ulrich. Whitaker, Jerry. "Communications Receivers: DSP, Software Radios, and Design." 3rd Edition. McGraw-Hill. 2001.

[7] Vaughan, Rodney G. Scott, Neil L. White D. Rod. "The Theory of Bandpass Sampling." IEEE Transactions on Signal Processing, Vol. 39, No. 9, pp.1973-1984, September 1991.

[8] Farrell, David J. Williams, David M. "Implementation of Digital Filters in Programmable Logic Devices." Class 551, Embedded Systems Conference, San Francisco, Spring 2001.

[9] Farrell D., Oakley A., and Lyons R.; "Discrete-Time Quadrature FM Detection," *IEEE Signal Processing Magazine*, September 2005

[10] "A Technical Tutorial on Digital Signal Synthesis," Analog Devices 1999.

[11] Lathi B.P.; "Modern Digital and Analog Communication Systems." 3rd Edition. Oxford University Press. 1998.

[12] Sayre Cotter W.; "Complete Wireless Design." McGraw-Hill. 2001.

Suggested Reading Continued

[13] "United States RBDS Standard" National Association of Broadcasters. April 1998.[14] R. Lacoste, "Direct Digital Synthesis 101", *Circuit cellar* 217, 2008

Demonstration System

A VHF FM Transceiver

- Utilizes a conventional mixer front end with an IF of 10.7MHz
- A high speed ADC samples the IF at 66.5MHz.
- A modular FPGA board decimates the signal and performs the modulation and demodulation.

Demonstration System



The Digital Radio Kit demonstration system is available for sale online at <u>www.cepd.com</u>
Source code and schematics are included with the purchase.
If you are interested in keeping current with what CEPD is doing, please sign up for our newsletter at http://visitor.constantcontact.com/email.jsp?m=1102433537278


© 2009 by CEPD, Inc. www.cepd.com

Beginning of Extra Supplemental Slides (the following were excluded from the talk)




FM Modulation – Pre-emphasis

- Preemphasizing the transmitted signal can reduce noise greatly.
 - Noise increases linearly with frequency.
 - Weaker high frequency components (beyond 2.1kHz) are boosted before the modulator using a preemphasis filter with a transfer function of $H_p(j\omega)$.
 - The higher frequency components are deemphasized in the receiver using a deemphasis filter with a transfer function of $1/H_p(j\omega)$.



FM Modulation and Radio Data Systems (RDS)

- RDS uses a 57kHz subcarrier (3rd harmonic of 19kHz pilot).
- Transmits data at 1187.5 bits per second with error correction.




FM Modulation and Hybrid Digital Radio (HD)

- HD Radio combines analog and digital signals into an AM or FM radio station's bandwidth.
- HD Radio provides nearly CD quality audio (CD quality is available with 100kbps transmission).
- There are 4 FM hybrid digital/analog modes offered: 100, 112, 125, and 150kbps. A pure digital option with up to 300kbps enabling extra features.
- In regular hybrid mode a station uses full 130kHz analog bandwidth and an extra 70kHz for the digital signals (using 400kHz total).
- Uses Coded Orthogonal Frequency Division Multiplexing (COFDM)

Overview of DDS Architecture

- A simple sine wave oscillator can be created using a reference clock, counter, and sine wave look up table.
 - This implementation is not flexible for generating different frequencies as to generate other frequencies requires changes to the reference clock.
- Modulation based on divide counters are difficult to implement as division is required to move between time and frequency.

Performance of FM Modulator




What is meant by "portable VHDL"

- The code is not vendor specific
- IP cores are not used
- All of the source code is visible to the designer

```
-- Example: The Hilbert Transform
w0 1 <= x;
B0W0_1 <= b0_1 * w0_1;
B2W2_1 <= b2_1 * w2_1;
rightsum1 <= B0W0_1 + B2W2_1;
PROCESS (reset, demodClk) BEGIN
 IF (reset = '1') THEN
   w1 1 <= (others = '0'); -- clear taps
   w2 1 <= (others => '0');
   y_1 <= (others => '0');
ELSIF (demodClk'EVENT and demodClk = '1') THEN
   w2 1 <= w1 1; -- update taps
   w1_1 <= w0_1;
  y_1 <= rightsum1(31 DOWNTO 16); -- right shift for Q16
END IF:
END PROCESS;
```

Digital Radio Sensitivity



Fixed-point Representation

12 bit Format	Represents	Range	Approximate resolution
Q0	Whole numbers	-2048 to 2047	1
Q1	Fractional Numbers	-1024 to 1023.5	0.5
Q10	Fractional Numbers	-2 to 1.999	0.001
Q12	Fractional Numbers	-0.5 to 0.4999	0.00024

2¹ 2⁰ 2⁻¹ 2⁻² 2⁻³ 2⁻⁴ 2⁻⁵ 2⁻⁶ 2⁻⁷ 2⁻⁸ 2⁻⁹ 2⁻¹⁰

 $1.3125 = 01_010100000 Q10$

FPGA Implementation of the Demodulator

- The coefficients are 20 bit Q16
- Intermediate registers are used to introduce sample delays and reduce the FPGA speed requirements

