

Overvoltage Protection and Arrester Selection for Large Wind Plants

Reigh Walling
GE Energy




GE imagination at work



Metal-Oxide Surge Arresters

- Near-ideal “clamp” of voltage across arrester
- Draws whatever current needed to clamp voltage
- Can fail from excessive energy
- Sensitive to stiff voltages for extended durations



2 /

Overvoltages on Wind Plant MV Collector

Arrester protects equipment from these

- **Lightning**
 - Coupling through substation transformer
 - "Sneak paths" from tower strikes
- **Switching transients**
 - Coupling through substation transformer
 - Capacitor bank switching and restrikes
 - Feeder energization


Arrester selected to "avoid" these

- **Temporary overvoltages**
 - Ground faults
 - Feeder islanding, loss of ground reference
- **Continuous operating voltages**

3 /

Surge Arrester Parameters

- Maximum continuous operating voltage (MCOV)
- Temporary overvoltage capability




- Duty cycle rating - legacy of obsolete technology
- Discharge voltage - at specified currents and waveshape
- Energy capability

4 /

Insulation Coordination

The process of selecting equipment insulation levels, surge arrester ratings and surge arrester locations such that:

- *Equipment voltage withstand is not exceeded*
- *Surge arresters survive*



5 /

Classic Insulation Coordination Process

1. Select arrester rating meeting MCOV and TOV constraints
2. Determine arrester protective level at a selected "coordinating current"
3. Select arrester location with respect to protected equipment
4. Determine voltage across each equipment – consider separation distance and lead length
5. Select equipment insulation level
6. Check to ensure protective margin is at least 20%
7. If not, revise design, and repeat Steps 1 – 6.

6 /

The Realities of Wind Plant Collectors


- Vast majority of North American wind plants use 34.5 kV collector systems for:
 - Capacity
 - "Reach"
 - Efficiency
- Commodity distribution-class equipment is preferred for economics
- 34.5 kV utility distribution feeders are almost always multigrounded-wye
 - Therefore, most equipment is available only up to 150 kV BIL
- MCOV and TOV are severe constraints in most wind plants
- Arrester application on wind plant collectors is often tightly constrained from both ends

7 /

Maximum Continuous Operating Voltage

Consider:

- Maximum grid operating voltage
- Substation transformer tap
- Rated wind plant real power output
- Maximum required reactive output




8 /

Temporary Overvoltages

- Excess capacitive compensation
 - e.g., tripping of VAR demand
- Ground faults; unfaulted phase voltage rise
 - In an effectively grounded system, voltages may rise as high as 1.35 p.u.
 - Some wind plants have high-impedance grounding; unfaulted phase voltage can rise > 1.73 p.u.
- Collector feeder isolation

9 /

Collector Feeder Isolation



Run-on is more likely with ride-through requirements

10 /

The Complications


Overvoltages on an “ungrounded” collector cable can be far greater than 173% of normal...

- Feeder cable capacitance
- Transformer saturation
- WTG interaction

11 /

Cable Capacitance

- Cable capacitance provides a high impedance “ground” with a negative reactance
- Can greatly amplify over voltage due to resonance




12 /


Transformer Saturation

Transformer saturation usually **does not** reduce crest voltages

- Fundamental voltage reduced, but
- Large amount of harmonic current injected
- Harmonics interact with system resonance to create high crest overvoltages



Only detailed simulation can determine the peak overvoltages



5-leg wound core configuration used on typical padmounts requires special models

13 /

Wind Turbine Generator Interaction

Induction generators

- Continue to generate if sufficient capacitance is present (*self-excitation*)
- Cable capacitance and pf capacitors, relative to WTG rating
- Voltage uncontrolled, WTG voltage can become high if sufficient capacitance islanded with generators

Converters (full conversion and DFAG)


- Continue to create a voltage unless tripped
- Can adversely interact with the high impedance

WTG run-on after feeder isolation is an issue for all technologies

14 /

Simulation Results – Induction Wind Turbine Generator

- Ground fault to 70% voltage on one phase
- 900' of 34.5 kV cable per WTG MVA + 0.51 p.u. power factor caps



Solutions to the Feeder Isolation Issue



1. Trip Wind Turbine Generators

Local detection is generally not effective

- Initial fault cannot be readily distinguished from grid ride-through event
- Overvoltage not always visible to WTG
- Islanding detection is inherently too late


Transfer trip

- Requires high-speed protection-grade communication (not ordinary SCADA)
- May need to delay collector breakers to allow WTGs to trip first

17 /

2. Provide Ground Sources

- Install dedicated grounding transformers on each collector string




- Grounding transformer sizing requires detailed simulation analysis

18 /

3. Use a Grounding Switch

Synchronized, interlocked grounding switch applies a 3-phase fault to the feeder immediately after the feeder breaker interrupts




19 /

Arrester Placement



Arrester Placement on MV Collector

34.5 kV feeder example, using 150 kV BIL equipment



21 /

Conclusions

- Overvoltage protection and arrester application generally similar to that for utility distribution systems
- Special considerations for wind plants:
 - Equipment generally designed for multigrounded-wye distribution used for a uni-grounded (or hi-Z grounded) wind collector
 - TOV from islanded feeder scenario can make it impossible to achieve proper insulation coordination
 - There are means to mitigate severe TOV
- Proper insulation coordination can provide a more reliable wind plant

22 /